



Save Code list for future reference Refer to the setup procedure below and look up the 4 digit code for your brand of TV, DVD, etc., from the list below. Refer to your XRU9M User's Manual for more information.

TV including LCD, Plasma, and Panel

ABEX	0185	CURTIS MATHES	0031 0105 0130	HYUNDAI	1134	MITSUBISHI	0005 0151 0051 0004	RADIO SHACK	0031 0004 0048 0049	TEKNIKA	0031 0004 0005 0009	SONY SATHD300	0623	GE	0225 0311 0335	OPTONICA	0354 0300	TECHNICS	0292	NAD	0721 0743	iPOD	0884	AT&T	1753 0511	
ACER	1163	DAEWOO ...0130 0004 0009 0100 00050004 0009 0000 0040	ILO	0198 1070 1024 1023	MONIVISION	0009 0022 0141 01800053 0170 0009 0227 03420053 0170 0009 0227 03420051 0109 0101 0109 0101	SONY SATHD100	06230342 0354 0278 02920225 0311 0335	ARION	0256 0310	TECHWOOD	1071	TECHWOOD	1071	NAKAMICHI	0693 0694 0831	JVC	0790 0813 0819	BELL	1755
ACME	00160138 0043 0140 0039 0444 0080 00420109 0358 0001 00150146 0189 1139 1113005300360002 0141 01800000 0012 0041 0042 00950000 0012 0041 0042 00950117	SONY SATHD200	06230227 0245 03380225 0311 03350693 0694 08310256 0310	TEKNIKA	0227 0245 0325 0251 0292	TEKNIKA	0227 0245 0325 0251 0292	NEC	0690	KENWOOD	0881 0683 0808	BELL SOUTH	0527
ADA	00060058 0017 0010 0126 0018 0127 0019	CXC	0053 0042	IMA	005300310607 06410607 06410117	TOSHIBA DST3100	06230329 0346 02340329 0346 02340780 0782 07880329 0346 02340225 0437 0292	TMK	0354 0249 0301	TMK	0354 0249 0301	NEXXTECH	0816 0828 0832 0869	CABLETENA	0468	
ADC	0001 0010	DAEWOON	0000 0144	IN FOCUS	0000	MONTGOMERY WARD	0001 00000004 00010004 00010117	TOSHIBA DW65X91	06410354 0375 04070354 0375 04070789 0829 0854 08610354 0375 04070369 0234 0332	GO-VIDEO	0354 0375 0407	GO-VIDEO	0354 0375 0407	KODA	0763	CABLEVISION	0468	
ADMIRAL	0135 0020 0226 0001	DAEWOO ...0130 0004 0009 0100 00050109 0358 0001 0015	INFINITY	0062 0288	MOTEAVA	0049 10130004 01860004 01860117	TOSHIBA DST3000	06410426 0455 0971 03680426 0455 0971 03680358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	PHILCO	0287 0225 0235 0292	PHILCO	0287 0225 0235 0292	NIKKO	0665 0673 0676	CABLEVISION	0512	
ADVENT	1171 0116 0167 0176 0922	DAEWOO ...0130 0004 0009 0100 00050109 0358 0001 0015	INITIAL	1070 0146 1085 1109	MOTOROLA	0020 0003019801980117	ZENITH DTV1080	06340251 02450251 02450358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	PHILIPS	0287 0225 0235 0292	PHILIPS	0287 0225 0235 0292	NSM	0666	CABLEVISION	0512	
ADVENTURA	0174	DAEWOO ...0130 0004 0009 0100 00050109 0358 0001 0015	INSIGNIA	1181 1180 1175 1171	MTC	0004 0005 0009 0105 0109 00140004 00090004 00090117	ZENITH HDSAT420	06340456 0286 0292 09690456 0286 0292 09690789 0829 0854 08610369 0234 03320369 0234 0332	TRUTECH	0456 0286 0292 0969	TRUTECH	0456 0286 0292 0969	ONKYO	0695 0696 0722 0811	CENTURY	0471	
AIKO	0058	DAYTRON	0004 00090103 0189 0217 0135 0133 0116 01671148 0456 0029 0905 1406 1407 1408	MULTITECH	00530004 00090004 00090117	ZENITH HDSAT520	06340234 02540234 02540358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	PHILIPS-MAGNAVOX	0287 0225 0235 0292	PHILIPS-MAGNAVOX	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
AIWA	0195 0196 0227 0269	DELL	0209 0028 013201148 0456 0029 0905 1406 1407 1408	INTEGRA	018100840394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410117	ZENITH HDSAT520	06340105 0049 0095 0170 0260 03580105 0049 0095 0170 0260 03580358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HARWOOD	0287 0225 0235 0292	HARWOOD	0287 0225 0235 0292	PANASONIC	0698 0699 0700 0744 0747 0751	CLEARMAX	0462	
AKAI	0105 0002 0077 1137	DIAMOND VISION	0210 094801148 0456 0029 0905 1406 1407 1408	INTEGRA	018100840394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HEADQUARTER	0287 0225 0235 0292	HEADQUARTER	0287 0225 0235 0292	NELSON	0377 0234	COGECO	0511	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HI-Q	0287 0225 0235 0292	HI-Q	0287 0225 0235 0292	NEO	0725	COLOR VOICE	0472 0473	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006	DIGIMATE	10170103 0189 0217 0135 0133 0116 0167	INTEQ	012101740004 0009 0109 01850004 0009 0109 01850117	ZENITH HDSAT520	06340394 0924 0012 0095 0117 01410394 0924 0012 0095 0117 01410358 0369 0924 0398 0274 03410287 0225 0235 02920287 0225 0235 0292	HITACHI	0287 0225 0235 0292	HITACHI	0287 0225 0235 0292	OPTIMUS	0667 0668 0678 0679 0697	CITIZEN	0471	
ALCANTARA	0006																									

SIGNAL	0474
SIGNATURE	0463
SL MARX	0474
SPRUCER	0460
STANDARD	0499
STAR SIGHT	0507
STAR TRAK	0516
STARCOM	0461 0518
STARGATE	0474
TANDY	0500
TELEVIEW	0474
TEXSCAN	0499
TIME WARNER	0529 0512 0506
TOCOM	0464 0501 0513
TOSHIBA	0486
TV86	0487
UNIKA	0468 0469 0471
UNITED CABLE	0461
UNIVERSAL	0468 0469 0470
UNIVERSAL	0471 0502 0524
VERIZON	0512 0529
VIDEO TECH	0550
VIDEOTRON	0512
VIDEOWAY	0504
VIEWSTAR	0475 0485 0487 0500
VISIONETICS	1046
ZENITH	0503 0525 0471
ZENITH	0486 0521 0522 0523
ZENITH NETWORK	0527

SATELLITE

(Including Set-Top Boxes WebTV, DTV).
Use codes (A) (B) (C) if you have 2 or more of the same device.

ADTH	1033
AMPLICA	0575
BELL	0655 0628
BELL EXPRESSVU	0654 0647
BELL	0655 0628
CENTURY	0547
CHANNEL MASTER	0577 0578 0579
CHAPPARAL	0560 0561
CHEYENNE	0561
COOLSAT	1036 0546
DIGIWAU	1034
DIRECTV	1049 1766 1767 1768 0622
.....	0632 0629 0623 0576 0586 0616 0613
.....	0630 0634 0636 0638 0641 0652 0653
.....	0657 0659 0607 0619 0537 0538 0539
DISH NETWORK	0628 0655 (A)
.....	0647 (B) 0612 0654 0588 0589 0590
DISHPRO	0588 0589 0590 0654
DRAKE	0562 0574 0587
DREAMBOX	0620
DX ANTENNA	0568 0582
ECHOSPHERE	0628
ECHOSTAR	0628 0655 (A) 0647 (B)
.....	0612 0654 0588 0589 0590
EXPRESSVU	0654 0647 0655 0628
FORTEC STAR	0569 0555 0556
.....	0557 0558 0559
FUJITSU	0591 0592
GE	1769 1032 0636 0649 0637
.....	0622 0653 0650 0651 0652
GEMINI	0595

GENERAL INSTRUMENT (GI)	0617 0634 0656 0595
.....	0627 (A) 0642 (B) 0643 (C) 0644 (D)
.....	0648 0640 0645 0564 0565 0566 0593

DVD/Blu-ray

ZENITH	0617 0634 0656 0595
.....	0646 0562 0574 0587 0635
ACESONIC	1119
ADVENT	0922
AFREEY	0417
AIWA	0414
AKAI	0395 0435 1105 1113
ALLEGRO	0245 0405
AMES	0431
AMW	0917 0918
ANABA	0961
APEX	0386 0390 0391 0392
.....	0424 0430 0436 0439 0445
.....	0457 0459 0938 0913 0401 0949
ASPIRE	0933
ASTAR	1093
A-TREND	0393
AUDIOVOX	1390 0921 1117
AXION	0921
B & K	0978
BLAUPUNKT	0430
BLUESKY	0415 0445 1125
BLU-RAY	1500 1411 1403 1399 1398
.....	1397 1396 1389 1129 0458 0405
BODYSONIC	0417
BOSE	0672
BOSS	0911
BOSTON ACOUSTIC	1098
BRITANIA	1395
BROKSONIC	0932 0967 0394
CAVS	1115
CENTRIOS	0951 1067 1068
.....	0921 1054 1055 1059 1060
.....	1061 1064 1065 1062 0449
CHANGHONG	0401
CINEVISION	0405
CITECH	1073
CITIZEN	1073
CLASSIC	0431 1051 0401
COBY	0926 0946 0947 0916 0445
.....	0928 0894 1091 1101 1111 1112 1124
CONCEPT	0430
CONIA	0445
CONTEL	1401
CRITERION	0448
CURTIS INTERNATIONAL	0929
.....	0928 0894
CYBERHOME	1053 0393 0985 0939
CYBERVISION	1391
CYTRON	0446 0388
DAEWOO	0440 0441 0444 0971 0965
DENON	1411 0400 0421
DENZEL	0428
DESAY	0958
DIAMOND VISION	0948 0892 0896
DIGIX	0934
DIGITREX	0445
DISNEY	0458
DRIVE	1094
DUAL	0447 0984 0956
.....	0428 0446 1092
DURABRAND	0449 0405 0446
.....	1086 1087 1088 1089 1090
DVD 2000	0402

EIGERVISION	1116
ELTA	0434 0435
EMERSON	0405 0940
.....	0899 0456 0458
ESA	0956
ESCIENT	1412
FARENHEIT	0960
FISHER	0416
FUNAI	0456 0458 0899
GE	0409 0430
GOLDSTAR	0405
GO-VIDEO	0431 0937 0971 0454
.....	0902 0901 0407 0426 0455
GPX	0936 0944
GRADIENTE	0415 1393 1394
GREENHILL	0430
HAAZ	0451 0452
HAIER	0935
HARMAN KARDON	0427
HD-DVD	1403 1399 1398 1397
PIONEER	1398 1397 0403 0404
.....	0976 0977 0968 0909 1084
PIVA	1075
POLAROID	0385 0957
.....	0892 0949 1122
POLK AUDIO	0398 0408 0981
PORTLAND	0435 0952
POWER ACOUSTIK	1107
PROLINE	0415
PROSCAN	0409 0890
PROSONIC	0926
PROTRON	0925
PYLE	0894
RADIO SHACK	0449 0453 0919 0920
RCA	0409 0415 0430 0449
.....	0453 0920 0890 1123
REGENT	0931 1086
REOC	0451
RIO	0405
RJ TECHNOLOGY	1076 1097
ROSEN	0930
ROTEL	0406
SABA	0919
SAMSUNG	1389 1388 1387 0407
.....	0454 0942 0963 0891 1099 0455
SAMPO	0417
SANSUI	0394 0967
SANYO	0904 0449 0416
SEARS	0394 0456
SEG	0428
SELECTRON	1077 1078 1079
.....	1080 1081 1082 1083
SEMP	0388
SENSORY SCIENCE	0902
SHARP	1403 0397 0897 0908
SHERWOOD	0425
SHINCO	0430
SHINSONIC	0430
SONIC BLUE	0937
SONY	1396 0987 0988
.....	0989 0399 0986 0389
SOUNDSTORM	0910 0911
SOVA	1095
SUNGALE	0953 0947
SUPERSCAN	0456
SUPERSONIC	1400
SV2000	0456
SVA	0445 0908

NESA	0430 0962
NEXXTECH	1401 1066 0952 0954
.....	0955 0956 0934 1052 1054 1055
.....	1056 1057 1063 1064 0449 0949
NORCENT	0926 0982
.....	0927 0925 0928
ONKYO	0398 0422 0975
OPTIMUS	0404 0403
ORION	0394
ORITRON	0415 1060
PACIFIC	0446
PANASONIC	1399 0396 0400 0974
.....	0970 0437 0950 0387
PHILCO	1392
PHILIPS	1129 0966 0914 1127 1128
.....	1126 0398 0408 0423 0755 0979
.....	0981 0980 0456 0458 0969 1096
PHILIPS-MAGNAVOX	0398 0408
.....	0423 0979 0980
PIONEER	1398 1397 0403 0404
.....	0976 0977 0968 0909 1084
PIVA	1075
POLAROID	0385 0957
.....	0892 0949 1122
POLK AUDIO	0398 0408 0981
PORTLAND	0435 0952
POWER ACOUSTIK	1107
PROLINE	0415
PROSCAN	0409 0890
PROSONIC	0926
PROTRON	0925
PYLE	0894
RADIO SHACK	0449 0453 0919 0920
RCA	0409 0415 0430 0449
.....	0453 0920 0890 1123
REGENT	0931 1086
REOC	0451
RIO	0405
RJ TECHNOLOGY	1076 1097
ROSEN	0930
ROTEL	0406
SABA	0919
SAMSUNG	1389 1388 1387 0407
.....	0454 0942 0963 0891 1099 0455
SAMPO	0417
SANSUI	0394 0967
SANYO	0904 0449 0416
SEARS	0394 0456
SEG	0428
SELECTRON	1077 1078 1079
.....	1080 1081 1082 1083
SEMP	0388
SENSORY SCIENCE	0902
SHARP	1403 0397 0897 0908
SHERWOOD	0425
SHINCO	0430
SHINSONIC	0430
SONIC BLUE	0937
SONY	1396 0987 0988
.....	0989 0399 0986 0389
SOUNDSTORM	0910 0911
SOVA	1095
SUNGALE	0953 0947
SUPERSCAN	0456
SUPERSONIC	1400
SV2000	0456
SVA	0445 0908

SYLVANIA	0456 0458 1106 0899
SYMPHONIC	0456 0458 0899
TASCAM	0406
TEAC	0404 0449 0405
TECHNICS	0400
TECHWOOD	0433 1071 0408
TERAPIN	0943
TEVION	0388 0446 0447
.....	0448 0450 0451 0452
THETA DIGITAL	0404
TIVO	0912 0909
TOSHIBA	1110 1114 1120 0394
.....	0398 0973 0924 0983
TREDEX	0941
TRUTECH	1053 0971 1121
UNITED	0449
VENTURER	1120 0449
VIZIO	1500 1502 1501 1419
WHARFEDALE	0442 0417
WESTINGHOUSE	0987
WHITE WESTINGHOUSE	0458
X-BOX	0409
XENIUS	0388
YAMAHA	1402 0420 0979 0980 0408
YAMAKAWA	0438 0428 1058
ZENITH	0398 0405 0907

Laser Disc

DENON	0305
PIONEER	0305
PROSCAN	0308
RCA	0308
SANYO	0232
SONY	0323
ZENITH	0232

DVR

Use codes (A) (B) (C) if you have 2 or more of the same device.

AT&T	0373
BELL	0655 0628
BELL EXPRESSVU	0647 0655
CABLEVISION	0506
CHARTER	0533 0512
COMCAST	0533
COX	0533
DIRECTV	1049 1766 1767 1768
DISH NETWORK	0655 0647
DREAMBOX	0620
ECHOSTAR	0655 0647
EMTEC	1385 1386
EXPRESSVU	0647 0655
FORTEC STAR	0569 0555 0556
HUGHES	0580
HUGHES NETWORK	0621 0580
HUMAX	0912
ILICO	0506
ILO	0959
JVC	1072
LG	1080
LITEON	0959
MEDION	0959
MOTOROLA	0533

PANASONIC	0373 0387
PANSAT	1035
PHILIPS	0371 (A) 0344 (B) 0345 (C)
.....	0621
PINNACLE	1040 1041 1042
PIONEER	0909 0977 0506
POLAROID	1122
PROSCAN	0653
RCA	0409 0653
RCN	0533
REPLAYTV	0373
ROGERS	0506
SAMSUNG	1388 0583
SCIENTIFIC ATLANTA	0506
SONIC BLUE	0373
SONY	0372 0657 0359
.....	0987 0988 0989 0659
TIME WARNER	0506
TiVo	0371 0372 0344 0345
.....	0657 0983 0912 0909
TOSHIBA	1114 0983 0973
ULTIMATE TV	0653 0659
VERIZON	0533
VIDEOTRON	0506
ZENITH	0656

DVD Recorders, RW

Use codes (A) (B) (C) if you have 2 or more of the same device.

ASTAR	0894
APEX	0938
ASPIRE	0933
BROKSONIC	0967
CENTRIOS	0951 1060 1061
COBY	0894
CYBERHOME	0939
EMERSON	0899
FUNAI	0456
GO-VIDEO	0431 0902 0901
HITACHI	0419 0387
HUMAX	0912
ILO	0959
INSIGNIA	0907
JVC	0900 1072
KXD	0894
LG	0907
LITEON	0902 0898 0959
MAGNAVOX	1409 0979 (A) 0980 (B)
MEDION	0903 0959
MEMOREX	1050 1118
MUSTEK	0431
PANASONIC	0387
PHILIPS	1128 0979 (A) 0980 (B) 1096
PHILIPS-MAGNAVOX	0979 (A)
.....	0980 (B)
PIONEER	0977 0909 1084
POLAROID	0385
RCA	0409
SAMSUNG	1388 0891
SANYO	0904
SELECTRON	1080
SHARP	0897
SONY	0987 (A) 0988 (B) 0989 (C)

SYLVANIA	1106 0899
SYMPHONIC	0899
TOSHIBA	0973 0398 1114
TRUTECH	1053
YAMAHA	0979 (A) 0980 (B)
ZENITH	0907

Digital Picture Frames

AUDIOVOX	1729
COBY	1727
DIGITAL DECOR	1734
DIGITAL LIVING	1733
DYNEX	1729
INSIGNIA	1731
KODAK	1730 1720
MEMOREX	1726
NORCENT	1728
PANDIGITAL	1734 1723
PHOTOSHARE	1725
POLAROID	1734 1732 1722
ROYAL	1723
SMARTPARTS	1734 1721
TRUTECH	1724

Media Center PC

MCE	1100
MICROSOFT	1100
VISTA	1100

Wall Mount

VIZIO.....	0320
------------	------