


Program your TV (continued)

Programming your L32 is a simple TWO STEP process. All you need is your Remote Control.

STEP 1

If you connected your Signal Source to the **TV** (Regular Cable/Antenna), go to **STEP 2a**.

If you connected your Signal Source to the **DTV** (Digital Antenna / Cable), go to **STEP 2b**.



If you have digital cable service, you may be able to receive digital TV channels using the DTV input.





Please Note:

- Be sure the batteries in your remote are inserted correctly.
- Be sure you have pressed the "TV" button on the top left hand corner of your remote.

STEP 2a TV (Regular Cable/Antenna)

On your Remote Control...

- 1 Press the NTSC TV button.
- 2 Press the MENU button to show the ON SCREEN DISPLAY menu.
- 3 Press the **4** button two times to highlight the TV TUNER SETUP menu.
- 4 Press **▲** button twice to highlight TV/CABLE.
- 5 Use the **▲** button to select either TV (Antenna) or CABLE.
- 6 Press the **▲** button once more to highlight AUTO SEARCH to scan the available channels.
- 7 Use the **4** button to start the scan. Scanning for available channels could take several minutes.
- 8 Once scanning is finished, programming is complete.
- 9 Press Exit until ON SCREEN DISPLAY disappears.
- 10 If you don't get all the channels or are missing some, please refer to page 47 of your User Manual.




For advanced set ups, refer to pages 45-52 of your L32 Owner's Manual.

STEP 2b DTV (Digital Antenna / Cable)

Visit www.antennaweb.org to set up your antenna. (Optional)

On your Remote Control...

- 1 Press the DIGITAL HD button until you see DTV on the screen.
- 2 Press the MENU button on the remote to show the ON SCREEN DISPLAY menu.
- 3 Press the **4** button two times to highlight the TV TUNER SETUP menu.
- 4 Press **▲** to highlight TIME ZONE. Press **4** to select correct time zone.
- 5 Press **▲** to highlight CABLE/AIR/AUTO. Press **4** to select AUTO. Press **▲** to highlight SCAN, press OK. Scanning for available channels could take several minutes.
- 6 To finish programming press Exit three times until ON SCREEN DISPLAY disappears.



For advanced set ups, refer to pages 33-44 of your L32 Owner's Manual.

Programming Your Cable or Satellite Box Remote

Consult your Cable or Satellite Owner's Manual to determine if you need a 3, 4, or 5-digit code. If your Cable or Satellite Box requires:

- 3-digits, please use "627" (This code usually works with DISHNetwork.)
- 4-digits, please use "1758" or "0178"
- 5-digits, please use "11758" or "10178" (These codes usually work for DIRECTV.)

Install with A Pro
Know your VIZIO is at its Best.
Choose from four different levels of installation



Basic

- Setting up and connecting your VIZIO TV to your existing home theater or audio system located in the same room
- Programming of your VIZIO remote and 1 other remote to operate your display and cable or satellite box
- Up to 20 minutes of educational demonstration and orientation
- 1 year warranty on the installation

Deluxe

- Includes the Basic service plus wall mounting with surface-routing cabling
- Removing the stand from your VIZIO TV
- Mounting and securing the TV to the wall
- Neatly surface-routing cables from your video and audio equipment

Premium

- Includes the Basic service plus wall mounting with in wall cabling
- Removing the stand from your VIZIO TV
- Mounting and securing the TV to the wall
- Concealing your video and audio cables in a standard frame wall
- Concealing your power cable with track molding if necessary

All-Inclusive HDTV off-air Installation

- Includes equipment and installation for local off-air HDTV broadcast
- HDTV antenna optimized for your location
- Up to 125 feet of antenna cabling
- If needed up to 2 diplexers, antenna mount, mast, pre-amplifier, splitters
- Connecting antenna to your VIZIO TV

Extended Service Plans

We recommend you register your VIZIO product either at our website www.vizio.com or fill in your registration card and mail it in. For peace of mind and to protect your investment beyond the standard warranty, VIZIO offers on-site extended warranty service plans. Extended service plans are offered at 2, 3, 4 and 5 years. These plans give you additional coverage during the standard warranty period. Visit our website or call us to purchase a plan.

CALL 800-988-4196
FOR EXTENDED WARRANTY SERVICES

Optional Components



Enhance your VIZIO Experience.

When it comes to components and accessories, don't settle for less than VIZIO. We offer a full line of products specifically designed to accentuate your L32. To learn more about how you can enhance your VIZIO experience, call 888-VIZIOCE (888-849-4623) or visit www.vizio.com.



VIZIO High-Definition Certified Cables

Our VIZIO Certified HD cables carry the same standards of excellence as all our VIZIO products. Available in: DVI, HDMI and Component in lengths of 2, 5, and 10 meters.



VIZIO Certified Mounts

FLUSH MOUNT- turn your HDTV into a work of art
TILT MOUNT- adjust your HDTV for the maximum viewing angle
ARTICULATING ARM- position your HDTV exactly where you want it




L32 HDTV QUICKSTART GUIDE


Before You Begin

- Verify all of the contents of your pack
- Review safety guidelines in Owner's Manual
- Place LCD TV so the rear connectors are accessible
- Install AA batteries into the VIZIO Universal Remote Control
- Write down your L32's Serial Number (located on the back)
A S L _____

Contents:




Power Cord



A/V Cable

Red, White and Yellow connectors



Remote Control

Includes 2 AA Batteries




Documents

VIZIO L32 User Manual, VIP Brochure and Warranty Registration Card

The Best Connection

We highly recommend you use Digital High Definition (Digital HD) and Digital Antenna/Cable (DTV) whenever possible. Please keep in mind however that not all components are capable of this type of connection. Our color-coded chart will help explain which components are capable of connecting in Digital High Definition (Digital HD) and Digital Antenna/Cable (DTV). To receive HD programs from an HD cable box or HD satellite receiver, HDMI, DVI or Component video must be used. To receive HD programs from an antenna use DTV input. Standard TV, AV, or S-Video cannot pass HDTV signals.



Four Easy Steps Simply follow our color-coded Step Charts and you're done.

1) Choose items to connect to your L32

- Determine which type of Signal Source and any Additional Equipment you wish to connect to your L32.
- The colored dots under each Signal Source and Additional Equipment indicate which type of connections you may use to connect to your L32.

Signal Sources				Additional Equipment							
Antenna	Cable Box	Digital Cable	Satellite Box	Computer	Digital Camera	DVD	DVR	Game System	Sound System	VCR	Video Camera
		○	○			○	○				
●					●						
		●	●			●	●	●			
		●	●			●	●	●			
	●				●	●	●	●			
	●				●	●	●	●			
									●		
										●	

2) Choose equipment connection methods

- Using the colored dots from Step One, follow the row across to Step Two to match up the colored dots to the same colored connection method.
- Choose ONLY one method for each piece of equipment.

Connection Methods

DIGITAL HD TYPE: Digital High Definition QUALITY: Best Digital
DTV TYPE: Digital Antenna/Cable QUALITY: Best Digital
RGB TYPE: RGB Analog QUALITY: Best Analog
ANALOG HD1 TYPE: Component Analog QUALITY: Better Analog
ANALOG HD2 TYPE: Component Analog QUALITY: Better Analog
AV 1 TYPE: Analog QUALITY: Good Analog
AV 2 TYPE: Analog QUALITY: Good Analog
AV 3 TYPE: Analog QUALITY: Good Analog
TV TYPE: Antenna / Cable QUALITY: Good Analog
DTV AUDIO TYPE: Digital Audio Out QUALITY: Best Digital
AUDIO OUT TYPE: Analog Audio Out QUALITY: Good Analog

3) Select cables and make connections


- Once you have determined the connection methods from Step Two, follow the row to Step Three to determine what kind of cables you need and what the connections look like on your equipment.
- Following the color-coded system, use the appropriate cables and connect your Signal Source and Additional Equipment to the color-coded inputs on your L32. (Refer to Connection Map at bottom of page.)
- Once connected, turn on your L32 and all your equipment.

Cable Needed	My Equipment Has	My L32 has	Connection Reference
HDMI* HDMI* to DVI* & RCA Audio Or			DIGITAL HD Connected Equipment
Coaxial (RF) Cable			DTV ANT Connected Equipment (*DTV on INPUT Menu)
VGA Cable* & stereo mini-jack	Optional Audio	Optional Audio	RGB Connected Equipment
Component & Stereo RCA Cable*			ANALOG HD1 Connected Equipment
Component & Stereo RCA Cable*			ANALOG HD2 Connected Equipment
AV/RCA Cable			AV1 Connected Equipment
AV/RCA Cable			AV2 Connected Equipment
AV/RCA Cable or S-Video Cable*			AV3 Connected Equipment
Coaxial (RF) Cable*			TV Connected Equipment
Optical Audio Cable*			DTV AUDIO OUT Connected Equipment**
Stereo RCA Cable			AUDIO OUT Connected Equipment**

*RF Cable, HDMI Cable, DVI-HDMI cable, VGA cable, Audio mini-jack, Component Cable, Optical Audio Cable and Coaxial Splitter are not included. These cables are available at www.vizio.com. View back for more details. **Turn L32 speakers off. (See AUDIO ADJUSTMENT MENU.)

3 WAYS TO GET HDTV

- 1) Off-Air antenna (using the DTV antenna input). To see if you are antenna, visit www.antennaweb.org
- 2) Cable - Subscribe to HD programming through your local cable company (HD cable box required).
- 3) Satellite - subscribe to HD programming through Direct TV or Dish Network (HD satellite receiver required).



For more information, see your Owner's Manual, Chapter 2, CONNECTING EQUIPMENT, pages 16-29.

INPUT Menu



An optional coaxial splitter can be used to receive both standard and digital TV signals from cable or antenna*



©2006 V, Inc.



VIZIO provides wall mounts & Installation Services. (See Install with a Pro details on back) Visit www.vizio.com or call 1-888-VIZIOCE (888-849-4623) to order today.

銅西卡200磅/上油/4色(807*559mmmm)
FN:VIZIO-L32_MTK QSG_F(13007370).AI