

Save Code list for future use. Refer to the setup procedure below and look up the 4 digit code for your brand of TV, DVD, etc., from the list below. Refer to your XRU100 User’s Manual for more information.



TV including LCD, Plasma, and Panel

ABEX	0185
ACER	1163
ACME	0016
ADA	0006
ADC	0001 0010
ADMIRAL	0135 0020 0226 0001
ADVENT	1171 0116 0167 0176 0922
ADVENTURA	0174
AIKO	0058
AIWA	0195 0196 0227 0269
AKAI	0105 0002 0077 1137
.....	1138 1105 1113 1139
ALLERON	0051
AMARK	0020
AMTRON	0053
ANAM NATIONAL	0053 0003
.....	0025 0042 0193
AOC	0004 0005 0009 1009
.....	0014 0156 0175 0187
APEX	0214 0216 0215 1132 0401
ARCHER	0020
ASPECT	0059
AUDIOVOX	1164 1165
.....	0053 1019 1117
AXION	0177
BANG & OLUFSEN	0190
BELCOR	0004
BELL & HOWELL	0031 0049
.....	0000 0001
BENQ	0081 0083 0101 1150
BLUESKY	1155 0144
BRADFORD	0053
BROKSONIC	0147 0135
.....	0310 0394 0932
BROKWOOD	0004
CANDLE	0004 0009 0174 0008
CAPEHART	0175
CCE	1153
CELEBRITY	0002
CELERA	0214
CENTRIOS	0169
CENTURION	0009
CETRONIC	0042
CHANGHONG	0214 0401
CINERAL	0058 0144
CITIZEN	0004 0009 0053 0105 0109
.....	0189 0135 0001 0008 0042 0058
CLAIRTONE	0014
CLASSIC	0214 0401 0042
COBY	1091 1124
COLOR VOICE	0010
COLORTYME	0004 0009 0010
CONCERTO	0004 0009
CONCIERGE	0121
CONTEC	0053 0012 0014 0042
CORNEA	0050
CRAIG	0053 0042
CROSLEY	0062
CROWN	0053 0042
CTX	0020

CURTIS MATHES	0031 0105 0130
.....	0004 0009 0000 0049
.....	0109 0358 0001 0015
CXC	0053 0042
CYBERVISION	0144
DAEWOO ...	0130 0004 0009 0100 0005
.....	0138 0043 0140 0039 0444 0080 0042
.....	0058 0017 0010 0126 0018 0127 0019
DAYTRON	0004 0009
DELL	0209 0028 0132
DIAMOND VISION	0210 0948
.....	0092 0896
DIGIMATE	1017
DIGISTAR	1019 0165 0118 0116
.....	0167 0132 1020 1151 1152
DIMENSIA	0031 0000
DISNEY	0158 0135
DUKANE	0059 0072
DUMONT	0121 0004
DURABRAND	0133 0189 0135
.....	0153 0217 0157 1135
DYNASTY	0042
DYNEX	1181 1171 0135
ELECTROBAND	0002 0014
ELECTROHOME	0004 0009
.....	0003 0022
ELEKTRA	0001
ELEMENT	1025 1173
ELITE VIDEO	0197
EMERSON	1172 0004 0009 0044
.....	0135 0049 0051 0189 0053 0147
.....	0039 0130 0210 0227 0233 0265
.....	0266 0310 0325 0456 0040 0041
.....	0042 0021 0023 0024 0179 0045
.....	0025 0027 0030 0032 0034 0035 0037
ENVISION ...	1179 0004 0009 0074 1009
ESA	0189
FISHER	0049 0110 0268 0180 0012
FLUID	1025 1026 1027
FUJITSU	1178 0197 0051 1006
FUNAI	0051 0189 0053
.....	0227 0456 0042
FUTURETEC	0053 0042
GATEWAY	0046
GE	0031 0107 0164 0004
.....	0009 0044 0054 0000 0342
.....	0003 0125 0015 0022 0052 0087
GIBRALTER	0121 0004
GOLDSTAR	0004 0009 0005 0227
.....	0338 0012 0057 0080 0156
GPX	0944
GRADIENTE	1013 0004
.....	0153 1160 1159
GRUNDY	0051 0053
GUESTVISION	0201
GVISION	1005
HAIER	0081 0216 0217
.....	0157 1147 0935
HALLMARK	0004 0009
HARVARD	0053
HAUPPAUGE	1198
HEWLETT PACKARD	1015 1004
HISENSE	1176 0073 0182 0216 1016
HITACHI	0088 0059 0142 0060
.....	0072 0004 0009 0091 1002 0001
.....	0012 0061 0137 0139 0141 0179 0227

HYUNDAI	1134
ILO	0198 1070 1024 1023
.....	0146 0189 1139 1113
IMA	0053
IN FOCUS	0000
INFINITY	0062 0288
INITIAL	1070 0146 1085 1109
INSIGNIA	1181 1180 1175 1171
.....	0103 0189 0217 0135 0133 0116 0167
.....	1148 0456 0029 0905 1406 1407 1408
INTEGRA	0181
INTEQ	0121
JANEIL	0174
JBL	0062
JC PENNEY	0031 0004 0005 0009
.....	0105 0107 0109 0054 0000 0087
.....	0008 0012 0015 0022 0030 0052
JCB	0002
JENSEN	0004 0009 0133
JVC	0060 0026 0197 0069 0160
.....	0247 0923 0012 0065 0067 0141
KAWASAKI	0945
KAWASHO	0004 0009 0002
KAYPANI	0042
KEC	0042 0053
KENWOOD	0004 0009
KLH	0214
KLOSS NOVABEAM	0068 0174
KOGI	1005
KONKA	0053 0011 0016 0047
.....	0066 0103 0412 0413 0029
KTV	0053 0014 0021 0042 0070
KURAZAI	0001
LASONIC	0210 0948
LEGEND	0116
LG	0134 0004 0050 0009 0005 0155
.....	0132 0227 0338 0012 0057 0080 0156
LIQUIDVIDEO	0177 0168
LODGENET	1170 0031
.....	0202 0000 0001
LOEWE	0211 0062
LOGIK	0031 0000 0001
LUCE	0055
LUXMAN	0004 0009
LXI	0031 0004 0009 0049 0062
.....	0107 0109 0000 0227 0015
MAGNASONIC	0051
MAGNAVOX	1174 0062 0004 0009
.....	0183 1133 0226 0288
.....	0456 0008 0068 0075 0141
MAJESTIC	0031 0000 0001
MARANTZ	0062 0181 0004 0009
MAXENT	0046
MEDION	0213 0198 0158
MEGATRON	0004 0009 0059
MEI	0014
MEMOREX	1025 0004 0009 0049
.....	0051 0135 0031 0000
.....	1007 0268 0310 0001 0394
MGA	0004 0005 0009 0051
.....	0012 0022 0141 0180
MIDLAND ..	0031 0121 0054 0107 0015
MINTEK	0146
MINUTZ	0052
MISAKAI	0189

MITSUBISHI	0005 0151 0051 0004
.....	0009 0022 0141 0180
MONIVISION	0036
MONTGOMERY WARD	0031
.....	0001 0000
MOTEVA	0049 1013
MOTOROLA	0020 0003
MTC	0004 0005 0009 0105 0109 0014
MULTITECH	0053
MULTIVISION	0084
MYRON & DAVIS	0212
NAD	0004 0009 0109 0185
NEC	1384 0181 0004 0005
.....	0009 0003 0010 0095 0141
NET TV	0046 0124
NEXXTECH	1052 0167
NIKEI	0042
NIKKO	0004 0009 0058
NIKO	1143
NORCENT	0216 0043 0056
NTC	0058
OLEVIA	1027 1012 1140 1142 1156
ONCOMMAND	0201 1161
ONKING	0175
ONWA	0053 0042
OPTIMUS	0170 0185 0374 0381
OPTOMA	1028
OPTONICA	0020 0095
ORION	0121 0135 0035
PANASONIC	1182 0171 0148 0054
.....	0170 0062 0374 0381
.....	0437 0950 0003 0070
PHILCO	0062 0004 0005 0009 0183
.....	0011 1158 0068 0075 0141 0003 0008
PHILIPS	0154 1174 0062 0204 0184
.....	0208 0205 0206 0207 0004 0189 0183
.....	0199 0200 0081 1149 1154 0288 0456
.....	0003 0008 0068 0075 0086 0087 0141
PHILIPS-MAGNAVOX	0062 0204
.....	0207 0183 0226 0288
PILOT	0004
PIONEER	0185 0181 0072
.....	0004 0009 0090 0179
PIVA	1075
PLANAR	1007
POLAROID	1177 1169 1162
.....	1025 0214 0182 0173
.....	0133 1019 1136 0116 0029
PORTLAND	0004 0005
.....	0009 0138 0130
PRECISION	0166
PRICE CLUB	0105
PRIMA	1019 0165 0116 0167 0176
PRINCETON GRAPHICS	0020 0099
PRISM	0054
PROSCAN	0031 0107 0015
.....	0000 0162 0163
PROTON	0192 0004 0009
.....	1010 0093 0175 0186
PROTRON	1017 1157
PROVIEW	1025 1026 1027
PULSAR	0121 0004
QUASAR	0171 0148 0054 0170
.....	0062 0374 0381 0003 0070

RADIO SHACK ..	0031 0004 0048 0049
.....	0053 0170 0009 0227 0342
.....	0000 0012 0041 0042 0095
RCA	0031 0004 0048 0054 0094 0100
.....	0102 0107 0129 0191 0005 0009 0000
.....	0162 0163 0342 0003 0015 0022 0096
.....	0113 0125 0179 0187 0188
REALISTIC	0031 0004 0048 0049
.....	0053 0170 0009 0000
.....	0227 0012 0041 0042 0095
RHAPSODY	0014
RUNCO	0121 0181 0111
SAMPO	0124 0046 0004
.....	0009 0175 0012
SAMSUNG	0105 0077 0076 0109
.....	0007 0009 0004 0005 0085 0172
.....	0942 0358 0012 0015 0080 0104 0106
SAMSUX	0009
SAMTRON	0105
SANSUI	0135 0310 0394
SANTECA	0194
SANYO	0049 0097 0110 0004
.....	0268 0012 0108 0180
SCEPTRE	1167 1132 0149
SCOTCH	0004 0009
SCOTT	1139 0004 0009 0051
.....	0053 0024 0035 0042
SEARS	0031 0062 0049 0051 0105
.....	0004 0009 0107 0109 0110 0189 0000
.....	0112 0079 0394 0456 0012 0015 0180
SELECTRON	1022 1020 1021
SEMP	1001
SHARP	0079 0123 0063 0020 0004
.....	0009 0226 0266 0006 0095 0122
SHOGUN	0004
SIGNATURE	0031 0000 0001 0023
SIMPSON	0008
SONIC	0014
SONY	0128 0013 0002
.....	0071 0380 0152
SOUNDESIGN	0004 0009 0051
.....	0053 0008 0042
SOVA	1003 1095
SOYO	1130 1131
SPECTRA	0210
SPECTRAVISION	0203
SQUAREVIEW	0189
SSS	0004 0053 0042
STAR SIGHT	0064
STARLITE	0053
SUPERSCAN	0112 0079 0456
SUPERSONIC	0944
SUPRA	0004 0082
SUPREMACY	0174
SUPREME	0002
SVA	0216 0212
SYLVANIA	0062 0004 0009 0135
.....	0189 0183 1141 0227 0456
.....	0008 0068 0075 0141 0161
SYMPHONIC	0053 0189
.....	0227 0456 0024
SYNTAX	1027 1140 1142
TANDY	0020
TATUNG	0081 0198 0003
TECHNICS	0054
TECHWOOD	0004 0009 0054

TEKNIKA	0031 0004 0005 0009
.....	0051 0053 0105 0109 0170
.....	0000 0174 0001 0008 0012 0042
TELECATION	0117
TELERENT	0031 0000 0001
TERA	0004 0186
TEVION	0198
TMK	0004 0009
TOSHIBA	0159 0178 0109 0120 0181
.....	0105 0049 0095 0170 0260 0358
.....	0394 0924 0012 0095 0117 0141
TRUTECH	1029 1145 1121
UNIVERSAL	0052 0087
VENTURER	1183
VICTOR	0060
VIDEOCON	1166
VIDTECH	0004 0005 0009
VIEWSONIC	1179 0046
.....	0072 1014 1144
VIKING	0174
VIORE	1018
VIZIO	1000 0143 1222 1168 0112
.....	1322 1189 1169 0081 0050
WARDS	0031 0062 0004 0005
.....	0009 0051 0000 0068 0075 0087
.....	0095 0119 0052 0001 0008 0024
WESTINGHOUSE	0002 0143
.....	0114 1146
WHITE WESTINGHOUSE ..	0100 0130
.....	0138 0136 1008 0227 0080
YAMAHA	0170 0004 0005 0009
ZENITH	0121 0009 0050 0078 0091
.....	0138 0059 0131 0038 0111
.....	0134 0153 0064 0004 0135
.....	0226 0227 0247 0266 0288 0310
.....	0338 0358 0023 0039 0001 0058

VCR

ACCELE	0354
ADMIRAL	0226
ADVENTURA	0251
AIKO	0252
AIWA	0245 0227 0269 0251
AKAI	0227 0229 0228 0230
.....	0231 0254 0303 0337
ALLEGRO ..	0247 0329 0243 0245 0405
AMERICAN HIGH	0292
APEX	0949
ASHA	0354
AUDIO DYNAMICS ...	0376 0377 0234
AUDIOVOX	0245
BEAUMARK	0354
BELL & HOWELL	0268
BROKSONIC	0256 0250 0257 0310
.....	0394 0967 0237 0289
CALIX	0245
CANDLE	0240 0245 0354
.....	0234 0242 0244
CANON	0225 0339 0292
CAPEHART	0329
CARVER	0287
CCE	0252 0356
CINEVISION	0245 0405
CITIZEN	0240 0245 0252
.....	0354 0234 0242 0244

COLORTYME	0234
COLT	0356
CRAIG	0245 0354 0356 0248
CURTIS MATHES	0225 0287 0227
.....	0334 0354 0358 0234 0249 0292
CYBERNEX	0354

CD, cont.

TEAC	0676 0689 0699
.....0709 0710 0711 0856	
TECHNICS	0716 0733 0820 0862
THETA DIGITAL	0731
TOSHIBA	0721
VICTOR	0682
YAMAHA	0665 0712 0713 0724 0846
ZENITH	0676 0730 0759 0784 0850

Audio

AIWA	0839 0842 0851 0860
APEX	0436
APPLE iPod	0885
BOSE	0672 0774 0775
CARVER	0825
CENTRIOS	0762 0763
.....0764 1055 0854	
CITIZEN	0826
CRITERION	0448
DELPHI	0708
DENON	0803 0817 0852
DURABRAND	0776
FISHER	0814 0821
GOLDSTAR	0766
HARMAN KARDON	0804 0818
INSIGNIA	1066
iPOD	0884
JVC	0790 0813 0819
KENWOOD	0881 0683 0808
.....0816 0828 0832 0869	
KODA	0763
KOSS	0415
MAGNAVOX	0796 0814 0915 0756
MARANTZ	0688 0824
MITSUBISHI	0877
NAD	0721 0739 0743
NELSON	0854
NEO	0725
NEXXTECH	1066 1055 0780 0782
.....0788 0789 0829 0854 0861	
NORCENT	0928
ONKYO	0805 0811 0812 0975
OPTIMUS	0667 0747 0748 0749
.....0751 0752 0754 0793	
PANASONIC	0791 0810 0815 0823
.....0863 0864 0974 0950	
PHILIPS	0755 0814 0823
.....0824 0825 0756 0757	
PIONEER	0754 0752 0751 0880
.....0837 0866 0867 0878 0976	
RADIO SHACK	0706 0754 0793 0806
.....0865 0866 0867 0868 0875 0878 0879	
RCA	0717 0726 0772 0781 0795
.....0827 0845 0866 0867 0870 0871	
.....0872 0875 0878 0879 0449 0920	
REALISTIC	0822
REGENT	0776
RIO	0405 0787
SABA	0919
SAMSUNG	0454
SANYO	0705
SCOTT	0768
SHARP	0671 0684 0809
SHERWOOD	0706 0806 0858 0859

SIRIUS	0746 0684
SKYFI	0725
SONY	0753 0323 0778 0779
.....0785 0797 0798 0799 0833	
.....0834 0835 0836 0843 0986	
TAO	0725
TEAC	0710 0807 0855 0856 0857
TECHNICS	0791 0810 0815
.....0823 0863 0864	
TEVION	0484
VENTURER	0745
VIZIO	0660 0883
WONDER	0762
XM RADIO	0708 0725
YAMAHA	0801 0802 0838 0840 0841
.....0846 0847 0848 0849 0767	
ZENITH	0676 0730 0749 0759 0765
.....0766 0784 0814 0787 0850 0405	

Cable

ABC	0461 0463 0464 0465 0466
ADELPHIA	0512 0511
ALLEGRO	0524 0525
AMERICAST	0527
ANTRONIX	0468 0469
ARCHER	0468 0469 0470 0471
AT&T	1753 0511
BELL	1755
BELL SOUTH	0527
CABLETENNA	0468
CABLEVIEW	0468
CABLEVISION	0512
CENTURY	0471
CHARTER	0512 0529
CITIZEN	0471
CLEARMAX	0462
COGECO	0511
COLOR VOICE	0472 0473
COMCAST	0533 0543 0511
COMTRONICS	0474 0475
CONTEC	0476
COX	0529
DIGITAL MUSIC EXPRESS	0514
DIRECTOR	0511
EASTERN	0477
EVERQUEST	0474
GARRARD	0471
GC ELECTRONICS	0469
GE	0549
GEMINI	0536 0479
GENERAL INSTRUMENT (GI)	0509
.....0461 0465 0511 0513 0518	
.....0530 0531 0514 0464 0463	
GOLDSTAR	0494
HAMLIN	0461 0480 0481 0482
HITACHI	0463
ILICO	0512
JASCO	0471
JERROLD	0509 0461 0465 0518
.....0464 0511 0463 0526	
MAGNAVOX	0485
MEMOREX	0486
MOTOROLA	0533 0545 0529 1754
.....0509 0465 0513 0518 0530	
.....0531 0464 0511 0526 0463	
MOVIE TIME	0487

NOVAPLEX	0528
NOWTV	1045
NSC	0487
OAK	0476 0489
PACE	0532
PANASONIC	0460 0508
PARAGON	0486
PHILIPS	0471 0479 0485
.....0490 0491 0492	
PHILIPS-MAGNAVOX	0505 0534
PIONEER	0494 0478 0506 0493
PULSAR	0486
QUASAR	0486
RADIO SHACK	0517 0505 0534 0525
RCA	0460 0471 0507
RCN	0529
REALISTIC	0469
REGAL	0482
REGENCY	0477
REMBRANDT	0463
ROGERS	0512
RUNCO	0486
SAMSUNG	0494 0474
SCIENTIFIC ATLANTA	0512 0498
.....0497 0506 0535 0466 0496	
SHAW	0511
SIGNAL	0474
SIGNATURE	0463
SL MARX	0474
SPRUCER	0460
STANDARD	0499
STAR SIGHT	0507
STAR TRAK	0516
STARCOM	0461 0518
STARGATE	0474
TANDY	0500
TELEVIEW	0474
TEXSCAN	0499
TIME WARNER	0529 0512 0506
TOCOM	0464 0501 0513
TOSHIBA	0486
TV86	0487
UNIKA	0468 0469 0471
UNITED CABLE	0461
UNIVERSAL	0468 0469 0470
.....0471 0502 0524	
VERIZON	0512 0529
VIDEO TECH	0550
VIDEOTRON	0512
VIDEOWAY	0504
VIEWSTAR	0475 0485 0487 0500
VISIONETICS	1046
ZENITH	0503 0525 0471
.....0486 0521 0522 0523	
ZENITH NETWORK	0527

SATELLITE

(IncludingSet-Top Boxes WebTV, DTV).
Use codes (A) (B) (C) if you have 2 or more of the same device.

ADTH	1033
AMPLICA	0575
BELL	0655 0628
BELL EXPRESSVU	0654 0647
.....0655 0628	

CENTURY	0547
CHANNEL MASTER	0577 0578 0579
CHAPPARAL	0560 0561
CHEYENNE	0561
COOLSAT	1036 0546
DIGIWAY	1034
DIRECTV	1049 1766 1767 1768 0622
.....0632 0629 0623 0576 0586 0616 0613	
.....0630 0634 0636 0638 0641 0652 0653	
.....0657 0659 0607 0619 0537 0538 0539	
DISH NETWORK	0628 0655 (A)
.....0647 (B) 0612 0654 0588 0589 0590	
DISHPRO	0588 0589 0590 0654
DRAKE	0562 0574 0587
DREAMBOX	0620
DX ANTENNA	0568 0582
ECHOSPHERE	0628
ECHOSTAR	0628 0655 (A) 0647 (B)
.....0612 0654 0588 0589 0590	
EXPRESSVU	0654 0647 0655 0628
FORTEC STAR	0569 0555 0556
.....0557 0558 0559	
FUJITSU	0591 0592
GE	1769 1032 0636 0649 0637
.....0622 0653 0650 0651 0652	
GEMINI	0612 0585
GENERAL INSTRUMENT (GI)	0595
.....0627 (A) 0642 (B) 0643 (C) 0644 (D)	
.....0648 0640 0645 0564 0565 0566 0593	
GLOBECAST	0553 1047
GO VIDEO	0610
HITACHI	0638 0629 0630
.....0632 0641 0607	
HUGHES NETWORK	0621 0641
.....0607 0580	
.....0632 (A) 0638 (B) 0629 (C) 0630 (D)	
JVC	0628 0612
KENWOOD	0598
LG	0607 0632 0641
LUXOR	0599
MACOM	0600
MAGNAVOX	0576 0612 0639
MICROYAL	1763
MITSUBISHI	0641 0632 0638
.....0629 0630 0607	
MOTOROLA	0640 0646 0648 0618
NEOSAT	1761
NET	0548 0606
NORSTAT	0601
NOVAPLEX	0978
ORION	1762
PACE	0614 0615 0646
PANASONIC	0626 0586 0596
PANSAT	1035 0584 1048
PHILIPS	0541 0576 0612 0621 0629
.....0630 0632 0638 0641 0639 0607 0605	
PHILIPS-MAGNAVOX	0576
.....0612 0639	
PIONEER	0604
PRIMESTAR	0627 0640
PROSAT	0563
PROSCAN	1032 0636 0637
.....0650 0653 0651 0652	
RCA	1032 0636 0649 0637 0622
.....0658 0653 0650 0651 0652 0098	
REALISTIC	0603 0567
SAMSONIC	1764

SAMSUNG	0594 0583 0613
.....0616 0619 0540	
SHARP	0604
SIERRA I II III	0561
SKY NETWORK	0542 0541 0614
.....0615 0646 0537 0538 0539	
SONY	0623 0657 0659 0585 0602
STAR SIGHT	0633
STAR TRAK	0608
STARCHOICE	0640 0645 0627
STS	0568 0570 0571
SUPER GUIDE	0609
SYLVANIA	0581
TELSAT	0547
THOMSON	0636 0541
TOSHIBA	0641 0632 0638 0629 0630
.....0607 0572 0624 0625 0631	
TVA	0551
ULTIMATE TV	0653 0659
UNIDEN	0633 0573 0611
UNITED	0597
VIDEO CIPHER II	0574
VIEWSAT	1037
VISIONTEC	0552
V-TECH	1039
WEB TV	0612 0585
ZENITH	0617 0634 0656 0595
.....0646 0562 0574 0587 0635	

DVD/Blu-ray

ACESONIC	1119
ADVENT	0922
AFREEY	0417
AIWA	0414
AKAI	0395 0435 1105 1113
ALLEGRO	0245 0405
AMES	0431
AMW	0917 0918
ANABA	0961
APEX	0386 0390 0391 0392
.....0424 0430 0436 0439 0445	
.....0457 0459 0938 0913 0401 0949	
ASPIRE	0933
ASTAR	1093
A-TREND	0393
AUDIOVOX	1390 0921 1117
AXION	0921
B & K	0978
BLAUPUNKT	0430
BLUESKY	0415 0445 1125
BLU-RAY	1500 1411 1403 1399 1398
.....1397 1396 1389 1129 0458 0405	
BODYSONIC	0417
BOSE	0672
BOSS	0911
BOSTON ACOUSTIC	1098
BRITANIA	1395
BROKSONIC	0932 0967 0394
CAVS	1115
CENTRIOS	0951 1067 1068
.....0921 1054 1055 1059 1060	
.....1061 1064 1065 1062 0449	
CHANGHONG	0401
CINEVISION	0405
CITECH	1073
CITIZEN	1073

CLASSIC	0431 1051 0401
COBY	0926 0946 0947 0916 0445
.....0928 0894 1091 1101 1111 1112 1124	
CONCEPT	0430
CONIA	0445
CONTEL	1401
CRITERION	0448
CURTIS INTERNATIONAL	0929
.....0928 0894	
CYBERHOME	1053 0393 0985 0939
CYBERVISION	1391
CYTRON	0446 0388
DAEWOO	0440 0441 0444 0971 0965
DENON	1411 0400 0421
DENZEL	0428
DESAY	0958
DIAMOND VISION	0948 0892 0896
DIGIX	0934
DIGITREX	0445
DISNEY	0458
DRIVE	1094
DUAL	0447 0984 0956
.....0428 0446 1092	
DURABRAND	0449 0405 0446
.....1086 1087 1088 1089 1090	
DVD 2000	0402
EIGERVISION	1116
ELTA	0434 0435
EMERSON	0405 0940
.....0899 0456 0458	
ESA	0956
ESCIENT	1412
FARENHEIT	0960
FISHER	0416
FUNAI	0456 0458 0899
GE	0409 0430
GOLDSTAR	0405
GO-VIDEO	0431 0937 0971 0454
.....0902 0901 0407 0426 0455	
GPX	0936 0944
GRADIENTE	0415 1393 1394
GREENHILL	0430
HAAZ	0451 0452
HAIER	0935
HARMAN KARDON	0427
HD-DVD	1403 1399 1398 1397
.....1396 1129 1110 0405	
HITACHI	0404 0407 0428 0419 0387
HITEKER	0445
HUMAX	0912
ILO	0959 1070 1113
INFINITY	0417
INITIAL	0430 1070 1085 1109
INSIGNIA	0458 1401 1070 1066
.....0456 0921 0430 0905 0907	
.....0405 1406 1407 1408 1413	
INTEGRA	0422
IRT	0894
JBL	0427
JVC	0398 0406 0408 0964
.....0900 1072 0418 0923	
JWIN	0390 0893 0895 1108
KAWASAKI	0945 0449
KENWOOD	0400 0429
KISS	0428
KLH	0430 0906 0386
KONKA	0410 0411 0412 0413 0905

KOSS	0415 0388
KXD	0894
LASONIC	1410 0451 0948
LENOMX	0931 0435 1087 1088
LG	1404 1400 0405 0972 0907
LINN	0443
LITEON	0982 0902 0898 0959 1069
LIQUIDVIDEO	0921
MAGNAVOX	1409 0398 0408 0458
.....0979 0981 0980 0456 0915 0914 0969	
MARANTZ	0398 0405
.....0408 0423 0981	
MAXENT	0923 0903
MEDION	0911 0446 0903 0896 0959
MEMOREX	0394 0446
.....1050 1118 1123	
MERIDIAN	0398
MICROSOFT	0409 1100
MICROVISION	0911
MINTEK	1095
MITSUBISHI	0430
MUSTEK	0431
MYRON & DAVIS	0962
NAD	1405 0405 0433
NAKAMICHI	0432
NEC	0405
NESA	0430 0962
NEXXTECH	1401 1066 0952 0954
.....0955 0956 0934 1052 1054 1055	
.....1056 1057 1063 1064 0449 0949	
NORCENT	0926 0982
.....0927 0925 0928	
ONKYO	0398 0422 0975
OPTIMUS	0404 0403
ORION	0394
ORITRON	041